

Fiche de configuration

Standard PS50-II

START



DEFAULT



USB DEFAULT



FRANCE



END

