

























Adaptustm Configuration Commands (quick sheet)

Start Settings		
DEFAULT.  Factory Defaults	MNUENA0.  Menu Commands Off	MNUENA1.  Menu Commands On

Interface Commands	General settings	
	Off	On
PAP232;232BAD9,WRD2.  RS232,115.200,8N1	ALLENA0.  All Symbologies Off	ALLENA1.  All Symbologies On
232INV0.(PC)  RS232 Inverted	SCNLED0.  Illumination off	SCNLED1.  Illumination on
232INV1.(UART)  RS232 Non-Inverted	SCNAIM0.  Aimer off	SCNAIM2.  Aimer Interlaced
TERMID130.  USB COM Port Emulation	SUFCA2.  Remove Suffix	SUFBK2990D0A.  Suffix [CR][LF]
TERMID124.  USB PC Keyboard Emulation	SHOTGN0.  Multiple Symbols Off	SHOTGN1.  Multiple Symbols On

Trigger Mode commands		
TRGMD0.  Manual Trigger	TRGMD3.  Presentation Mode	TRGMD6.  Snap + Ship

Xenon Plug & Play commands		
PAPHHF.  Manual Trigger (better DOF)	PAPSPN.  Streaming (better DOF)	PAPHHC.  Mobile Phone (manual)
PAPHHS.  Manual Trigger (better speed)	PAPSPE.  Streaming (better speed)	PAPSPC.  Mobile Phone (streaming)

5x80 / 4600 family RAW commands

\x16t\x0d.	send trigger signal
\x16u\x0d.	send untrigger signal
\x16y\x0DVENDOR?.	request vendor name
\x16y\x0dP_NAME?.	request product name
\x16y\x0dSERNUM?.	request s/n
\x16y\x0DUSBPID?.	request PID
\x16y\x0DUSBVID?.	request VID
\x16n,reset\x0d.	reset
\x16m\x0d"command".	e.g. \x16m\x0dSCNLED?.
\x16m\x0dREV_SW?.	display project revision number (MKS)
\x16m\x0dREV_WA?.	display firmware file number
\x16m\x0dREV_CC"string".	change the REV_CC string (in RAM only)
.....	
REVINF	wireless: request revision info for 2020base
:*:REVINF	wireless: request revision info for scanner